

**FDJ SERIES  
FRAME INSTALLATION**

①

NOMINAL DOOR HEIGHT +1"

NOMINAL DOOR WIDTH +2"

ADD TO DOOR OPENING DIMENSIONS: 2" TO WIDTH AND 1" TO HEIGHT. FOR A 3070 DOOR FRAME, THE ROUGH OPENING IS 38" x 85".

②

HEADER

INSTALL HEADER INTO POSITION APPROX. 1" FROM THE TOP AND THE CENTER OF THE ROUGH OPENING.

③

STRIKE JAMB

INSTALL STRIKE JAMB BY SLIDING OVER WALL AT TOP AND ENGAGING CORNER TABS INTO HEADER. PIVOT JAMB INTO PLACE.

④

REPEAT STEP #3 WITH HINGE JAMB. PULL HEADER DOWN TIGHTLY ONTO JAMBS. LOCK HEADER AND JAMBS TOGETHER BY BENDING OVER EXPOSED TABS.

⑤

BEND CORNER TABS TOWARD INSIDE OF FRAME.

⑥

TURN ADJUSTING SCREWS IN BOTH JAMBS COUNTERCLOCKWISE UNTIL ANCHOR IS RESTING AGAINST THE WALL.

⑦

IF FEASIBLE, HANG DOOR NOW AND ADJUST FRAME ON WALL TO ALLOW PROPER DOOR / FRAME CLEARANCES OR PLUMB FRAME WITH CARPENTER SQUARE AND/OR LEVEL. (ADJUST HEADER LEVELNESS BY SHIMMING UNDER JAMBS).

⑧

PUNCHED AND DIMPLED FOR A #10 DRYWALL SCREW

3/4"

3/4"

CHECK DOOR OPENING DIMENSION AT BASE OF FRAME (SAME DIMENSION AS BETWEEN JAMBS AT HEADER). SECURE JAMBS WITH DRYWALL SCREW (NOT FURNISHED) THOUGH PUNCHED AND DIMPLED HOLE AT THE BASE OF FRAME. BE SURE TO ATTACH SCREWS TO BOTH SIDES OF BOTH JAMB LEGS (4 PLACES).